


**VANGUARD MODELS:**  
 S/N: 2015474846 & BELOW:  
 5401150 (OGURA CLUTCH)  
 5405104 (WARNER CLUTCH)


**CYCLONIC MODELS:**  
 5409224

S/N: 2015474847 & ABOVE:  
 5409294


IGNITION SWITCH POSITION	CIRCUIT MAKE
1. OFF	G & M & A
2. RUN	B & L & A
3. START	B & L & S




**VANGUARD MODELS**  
 (S/N: 2015484846 & BELOW)



**JUMPER HARNESS - 5401204**  
 (S/N: 2015474846 & BELOW)




**BRIGGS & STRATTON ENGINE**  
 (VANGUARD MODELS)



**CYCLONIC MODELS**

**JUMPER HARNESS - 5409286**  
 (CYCLONIC MODELS)



**BRIGGS & STRATTON ENGINE**  
 (CYCLONIC MODELS)

